

## **KT I Lab Course**

## **Angular Correlation**

Assistant:

Alexander Kish

Students:

Fabian Stäger, Manuel Sommerhalder

Date of experiment:

24.01.2018







## **Contents**

1	Introduction	3
	1.1 The <sup>60</sup> Co Decay	3
	1.2 Angular Correlation	3
	1.3 Experimental Concept	4
2	Measurement Principle	5
	2.1 Experimental Set-Up	5
	2.2 Electronic Modules	5
3	Energy Spectrum	6
4	Calibration	7



#### 1 Introduction

The goal of this experiment is to measure the angular correlation function of  $\gamma$ -rays in a  $^{60}$ Co decay and compare it to theoretical predictions.

#### 1.1 The <sup>60</sup>Co Decay

 $^{60}$ Co is a synthetic isotope of cobalt with a half-life of 5.1 years. Through  $\beta^-$  decay it disintegrates into an excited  $^{60}$ Ni atom with an energy of 2505 keV and l=4 with positive parity. This nickel isotope thus emits two successive gamma rays with energies of 1172 keV and 1332 keV in order to reach its stable state of  $0^+$ . Since the intermediate state ( $2^+$ ) has a lifetime of around 1 ps, the two  $\gamma$ -rays can due to the finite experimental time resolution be treated as coincident. A schematic diagram of the  $^{60}$ Co decay is provided in figure 1.




Figure 1: Schematic illustration of the <sup>60</sup>Co Decay. [??]

#### 1.2 Angular Correlation

The two successive  $\gamma$ -rays are predicted to be emitted anisotropically relative to each other according to the general angular correlation function [??]:

$$W(\theta) = 1 + \sum_{i=1}^{l} a_i \cos^{2i} \theta \tag{1.1}$$

This function describes the probability for the latter gamma ray to be emitted at an angle  $\theta$  from the first one. 2l is the order of the lowest multipole in the cascade. In case of



the  $^{60}$ Co decay, both gamma rays are emitted during a transision of  $\Delta l$  = 2 and positive parity, so the dominant contribution is the electric quadrupole and the correlation function reduces to:

$$W(\theta) = 1 + a_1 \cos^2 \theta + a_2 \cos^4 \theta$$
 (1.2)

The coefficients  $a_1$  and  $a_2$  have been theoretically predicted by Dr. Hamilton for all combinations of angular momenta involved by consideration of state transitions using the Clebsch-Gordan-coefficients. These are summarized in figure 2

$J_2$	$J_2$	Multipoles	$a_1$	az
1	0	Dipole-Dipole	1	0
1	1	Dipole-Dipole	-1/3	0
1	2	Dipole-Dipole	-1/3	0
1	1	Quadrupole-Dipole	-1/3	0
1	2	Quadrupole-Dipole	3/7	0
1	3	Quadrupole-Dipole	-3/29	0
2	3	Dipole-Quadrupole	-3/29	0
2	2	Dipole-Quadrupole	3/7	0
2	1	Dipole-Quadrupole	-1/3	0
2	0	Quadrupole-Quadrupole	-3	4
2	1	Quadrupole-Quadrupole	5	-16/3
2	2	Quadrupole-Quadrupole	-15/13	16/1
2	3	Quadrupole-Quadrupole	0	-1/3
2	4	Quadrupole-Quadrupole	1/8	1/24

Figure 2: Coefficients  $a_1$  and  $a_2$  for different combinations of  $J_1$  and  $J_2$  for an atom deexciting into the ground state  $J_1 = 0$  [??]

Since the angular monenta of  $J_3$  = 4,  $J_2$  = 2,  $J_1$  = 0 are assumed for the  $^{60}$ Co decay, the expected correlation function has the following explicit form:

$$W(\theta) = 1 + \frac{1}{8}\cos^2\theta + \frac{1}{24}\cos^4\theta$$
 (1.3)

#### 1.3 Experimental Concept

The experimental setup, more throroughly described in section  $\ref{eq:constraint}$ , consists of two scintillation counters that detect the coincident  $\gamma$ -rays from different and adjustable relative angles. The rate of detected events is then plotted and compared to the theoretical description from formula 1.3.



## 2 Measurement Principle

- 2.1 Experimental Set-Up
- 2.2 Electronic Modules



# 3 Energy Spectrum



## 4 Calibration